





How to Program Your DVR Remote


1. Make sure your TV is on
2. Press and hold the TV button, until all four lights along the top of the remote blink




3. Press the power button



4. Press and release the up arrow (multiple times), until the TV turns off




5. Press OK




6. Turn the power to the TV back on using the Power button at the top of the remote.

7. Press and hold the TV button, until all four lights along the top of the remote blink again



8. Press the Volume up button.



9. Your remote should now be synced to your TV.

